

Copyright © 2016 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. H18GTMB

GAS TANK MINI BRA

10/18/2016

FITMENT:

HONDA GL1800 GOLDWING AND F6B 2001-NEWER

TOOLS NEEDED: 6MM ALLEN WRENCH

RUBBING ALCOHOL

DUST FREE TOWEL

**PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.**

**ESTIMATED INSTALLATION TIME: 20 TO 30 MIN.**

**INSTALLATION:**

1. USING A 6MM ALLEN WRENCH REMOVE THE FOUR BOLTS HOLDING THE PASSENGER HANDLES TO THE SEAT. SEE FIG. 1.
2. LIFT THE SEAT FROM THE REAR AND REMOVE IT. IF YOU HAVE A HEATED SEAT YOU WILL ALSO HAVE TO UNPLUG THE CONNECTOR UNDER THE SEAT AS YOU REMOVE IT.
3. USING RUBBING ALCOHOL AND A LINT FREE TOWEL CLEAN THE AREAS WHERE THE HOOK STRIPS ARE GOING TO BE ATTACHED. SEE FIG. 2 AND FIG. 4. LET DRY.
4. PLACE THE 2-1/2" LONG AND THE 4" LONG STRIPS OF HOOK ON THE GAS TANK AND SHELTER AS SHOWN IN FIG 2.
5. LAY THE BRA IN PLACE AS SHOWN IN FIG. 3 AND PUSH DOWN TO CONNECT THE HOOK AND LOOP STRIPS.
6. REINSTALL THE SEAT IN THE REVERSE ORDER YOU REMOVED IT. NOTE: THE PLASTIC TABS ON THE FRONT ON THE SEAT GO INTO THE TWO HOLES IN THE BRA.
7. ATTACHED THE 8" LONG STRIPS OF HOOK TO EACH SIDE AS SHOWN IN FIG. 4 FOLLOWING THE LOWER EDGE OF THE TOP SHELTER.
8. STRETCH THE BRA ON EACH SIDE AND ATTACH THE BOTTOM EDGES TO THE HOOK ON THE BIKE. SEE FIG. 5.
9. FOR BEST RESULTS LET CURE FOR 24 HOURS BEFORE RIDING THE BIKE.

